



Rainwater Harvesting



Stepwise do's and don'ts

Steps in rainwater harvesting cycle	Do's	Don'ts
Rain falls from the sky		
The rain falls onto the roof, which is the catchment	Clean the roof every 15 days and make sure there are no leaves on the roof	Don't use paints, chemicals or hazardous substances on the roof
The water from the roof is channelled through rainwater pipes	Make sure the pipes are well maintained	Don't break the pipes!
The first one litre per m ² of roof is separated using a 'First Rain Separator'	Make sure the first rain separator is emptied before and after every rain	Don't leave the first rain separator valve open! Remember to close it!
The remaining water then flows through a filter	Wash the jelly stones in the filter every two months and replace the mesh if it is damaged	Don't leave the filter open, make sure you close it with the Cudappah stone.
And into a storage tank Into a recharge well and into the ground	Clean the tank once every six months and make sure it is kept closed at all times	
The overflow flows into stormwater drains		